
Front Panel USB Port Firmware Update Instructions

RP5900 Series Firmware

Front Panel USB Port Firmware Update Instructions

1. Download the firmware folder from K.com webpage and perform copy (the files only, but not in a folder format) to a USB drive.
2. Remove the USB drive from the PC and insert it into the instrument's front panel USB port.
3. Begin firmware update by pressing: **[Menu] > System > Admin > Update**
4. Once the USB drive is detected, it will show the "Upgrade Now?" confirmation screen.
5. Press **Yes** to continue with the firmware update. After that, press **[Enter]** to start the update process.
6. The firmware update process is complete after the instrument rebooted.
7. Press **[Menu] > System > About** to check the firmware revision updated is correct.