
Web Interface Firmware Update Instructions

RP5900 Series Firmware

Web Interface Firmware Update Instructions

***Note:** EL4936A model is used as an example

1. Download the firmware folder from K.com webpage.
2. Enter the instrument's IP address or hostname in the browser's address bar to use the instrument's Web interface.
3. Click **Software Update** tab to update the instrument's firmware by inserting "Keysight" for Password.
4. Begin firmware update by:
 - i) click and select the downloaded .kfw file, or
 - ii) drag-and-drop the downloaded .kfw file to the Software Update box.

Press **Update** to start the update process.

 **KEYSIGHT**
TECHNOLOGIES

EL4936A
Serial number: CN25260024

Log Out 

Home Control Instrument **Software Update** Configure LAN 

Boot version	01.00,04.01
Software version	01.05-01.00-01.00

 Restart System

Software Update

Software update for embedded systems

Upload a software image below, or restart the system at the top right corner.

 Software Update

70.39MB
RP59_EL49-V01.10-00.02-01.06-01.01.kfw

 Update not started. 00:00:00

0%

Update

Stop

5. The firmware update process is complete after the instrument is rebooted.



6. Press **[Menu] > System > About** to check the firmware revision updated is correct.