
Keysight i7090 Software

Notices

© Keysight Technologies 2025

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

Q3000-96004

Edition

Edition 3, October 2025
Printed in Malaysia

Published by:
Keysight Technologies
1400 Fountaingrove Parkway
Santa Rosa, CA 95403-1738
United States

Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software.

Safety Notices

WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

Installing the Keysight i7090 Software

Table 1 System requirements

Processor	Recommended Intel Core i7-8700
Operating System	Windows 10 Pro, version 22H2, 64-bit Windows 10 Enterprise, version 22H2, 64-bit Window 11 Pro, version 23H2, 64-bit Ensure that all Windows updates are installed
Memory	Minimum 8 GB of RAM
Disk Space	Recommended 10 GB Minimum 5 GB Must be on C: drive
Display Settings	Minimum 1280 x 1024, 16-bit
Language Setting	Must be English (United States)

NOTE

- All software must be installed to C: drive, which must also be the drive where the operating system is installed
- Disable anti-virus software before starting the installation. Otherwise, some of the components might not install properly. Remember to reactivate the anti-virus software after the i7090 software is installed.

In Case of Difficulty...

To contact Keysight technical support, go to www.keysight.com/find/contactus.

Before installing the i7090 software

- Turn on .NET Framework.
 - a Open Control Panel, click **Programs and Features** and click **Turn Windows features on or off**.
 - b In the Windows features dialog box, click **.NET Framework 3.5 (includes .NET 2.0 and 3.0)** and click **OK**.
 - c Restart the computer if prompted.
- If an earlier version of the i7090 software is installed, uninstall it.
Open Control Panel, click **Programs and Features**, select the **Keysight i7090** software and click **Uninstall**.

Install the software

- 1 There are two installers for the 64-bit and 32-bit versions of the i7090 software.
 - Keysight_i7090_<software version>_win_x64.exe
 - Keysight_i7090_<software version>_win_x86.exeInstall the version that suits your needs, by double-clicking the appropriate .exe file.
- 2 If the User Account Control dialog box appears, click **Yes** to allow the installation to continue.
- 3 Follow the instructions on the screen to complete the software installation.

i7090 users on testhead controller

The following Users are created during software installation.

Table 2 Default User names and passwords

User name	Password
calibrate	i7090MPIC1
operator	i7090MPIC1



This information is subject to change
without notice.

© Keysight Technologies 2025
Edition 3, October 2025



Q3000-96004

www.keysight.com