
Keysight EasyEXPERT+ Software for B1500 Mainframe

Installation Instructions

This document provides installation instructions for the EasyEXPERT+ software.

More details about this product are available at: [B1500 Driver, Firmware and Software | Keysight](#)

Notices

© Copyright 2006 - 2026 Keysight Technologies, Inc.

The information contained in this document is subject to change without notice.

Keysight Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Keysight Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Manual Part Number
B1500-90941

Edition
Edition 3, May 2026

About this document

This document contains the following:

- Note
- Software Requirements
- Update Instructions

Software Requirements

To update EasyEXPERT Rev. A.05.04 or earlier to Rev. A.05.50 or later, the following software is required.

- Microsoft Windows Installer 3.1
- Microsoft .NET Framework 3.5 Service Pack 1

NOTE:

If any required software is not installed on your computer, install it in the sequence listed above.

For example, if Microsoft Windows Installer 3.1 is not installed, install it first, and then install Microsoft .NET Framework 3.5 Service Pack 1.

The required software is stored in the "Prerequisites" folder in this package.

Update Instructions

To update EasyEXPERT for the B1500, follow the procedure below.

1. If the downloaded file is saved on a PC, copy it to the B150xA using media such as a CD-R/DVD-R or a USB drive.
2. On the B150xA, if you see the [Start EasyEXPERT] button on the screen, close the window by clicking the "x" button on the title bar.
3. Extract the contents of the downloaded file into a working folder as follows.
 - a) Go to the folder where the downloaded file is saved, and open the folder.
 - b) Place the pointer on the downloaded file, right-click it, and select "Extract All...".

NOTE: If a third-party unzip tool is installed, the procedure above may not work. In this case, follow the instructions for that tool. The example below uses WinZip.

- a) Double-click the downloaded file, and then click "Unzip" on the menu bar.
 - b) Specify the folder, and then click "Unzip".
4. Double-click the EasyEXPERT folder.
 5. Double-click the executable file to start the installation, and follow the instructions in the setup wizard.
 6. Wait for the installation to complete, and then restart the B150xA.

Microsoft and Windows are registered trademarks of Microsoft Corporation. All other trademarks are the property of their respective owners.